



TANDEM INSTRUCTOR CURRENCY REQUIREMENTS

Tandem Instructors are divided into two groups:

1. Those who have under 500 tandem jumps.
2. Those who have over 500 tandem jumps.

To be current:

1. Tandem Instructors with less than 500 tandem jumps need to have made 1 tandem jump within the last 30 days on the Strong Tandem System. In order to become current they would need to make 1 tandem jump with an experienced skydiver* as the passenger. This jump is to be made under the supervision of a current Strong Certified Tandem Instructor after they review both normal and emergency procedures.
2. Tandem Instructors with more than 500 tandem jumps on the Strong Tandem System need to have made 1 tandem jump within the last 90 days on the Strong Tandem System. In order to become current they would need to make 1 tandem jump with an experienced skydiver* as the passenger after they review both normal and emergency procedures.
3. Any Tandem Instructor who has not made a tandem jump within the last 6 months would have to make 1 tandem jump with a current Tandem Instructor as the passenger, after they review both normal and emergency procedures.
4. Any Tandem Instructor who has not made a tandem jump within the last 12 months would have to attend a re-currency course with a Tandem Examiner.

*Passengers on re-currency jumps must have at least 100 jumps experience. In addition, they must wear an altimeter, have a ripcord for main canopy deployment attached to their harness and the safety handles, which allow the passenger to cut away and pull the reserve, must be in place.

"A Tandem Jump is not just another skydive"