



## **TANDEM INSTRUCTOR CURRENCY REQUIREMENTS**

### **Tandem Instructors are divided into two groups:**

1. Those who have under 500 tandem jumps.
2. Those who have over 500 tandem jumps.

### **To be current:**

1. Tandem Instructors with less than 500 tandem jumps need to have made 1 tandem jump within the last 30 days on the Strong Tandem System. In order to become current they would need to make 1 tandem jump with an experienced skydiver\* as the passenger. This jump is to be made under the supervision of a current Strong Certified Tandem Instructor after they review both normal and emergency procedures.
2. Tandem Instructors with more than 500 tandem jumps need to have made 1 tandem jump within the last 90 days on the Strong Tandem System. In order to become current they would need to make 1 tandem jump with an experienced skydiver\* as the passenger after they review both normal and emergency procedures.
3. Any Tandem Instructor who has not made a tandem jump within the last 6 months would have to make 1 tandem jump with a current Tandem Instructor as the passenger, after they review both normal and emergency procedures.
4. Any Tandem Instructor who has not made a tandem jump within the last 12 months would have to attend a re-currency course with a Tandem Examiner.

\*Passengers on re-currency jumps must have at least 100 jumps experience. In addition, they must wear an altimeter, have a ripcord for main canopy deployment attached to their harness and the safety handles, which allow the passenger to cut away and pull the reserve, must be in place.

***"A Tandem Jump is not just another skydive"***